

BO20E-05 Camera logic diagram

Signaltype

Serial data

Camera number	Real
Train number	Real
Train_X_Pos	Real
Train_Y_Pos	Real

Signaltype

Cam Data

CalibrationX1	Real
CalibrationX2	Real
TrackNumberCalibration	Real
Pos1_HMI_Value	Real
Pos2_HMI_Value	Real
Train1_Y_Pos	Real
Train2_Y_Pos	Real

